



IntGuard™ G6-009 GSM Alarm System Quick Start Guide

Thank you for purchasing IntGuard G6 high-quality GSM/PSTN Alarm System. The system has been carefully inspected, programmed and tested in factory and before we ship to you. Below steps can help you quickly get the system up running. For any questions please email to support@intguard.com right away. Your questions will be answered shortly.

1. Please refer “Terms and Conditions” at the end of this guide for the usage agreement of this product.
2. Check the package list
The box contains the following list of items:
 - a. Main Panel and its power adapter
 - b. Two pre-programmed pet-friendly motion sensor
 - c. Four pre-programmed door/window smart sensors
 - d. Two remote control fobs
 - e. Full Manual
 - f. Other small accessories such as PSTN line socket and PSTN phone cableNote that the panel’s front surface has a thin protective film on it. Leave it on the panel or till when you finish mounting the panel.
3. Do not turn the panel power on yet. This system supports both GSM wireless communication and also old-fashioned PSTN phone line. You can use either way or use both ways for added reliability. You must have good GSM signal in order to use GSM communication. We will show you how to setup GSM communication in a separate page.
In this quick start guide, we show you how to get PSTN phone line connected. To use PSTN phone line, follow below steps:
 - a. Plug in phone line socket to the back panel
 - b. Plug the included PSTN phone cable into your wall phone socket
 - c. Plug the other end of the PSTN phone cable into the phone line socket of alarm panel
 - d. Plug your existing phone cable to the other port of the alarm’s phone socket so that your existing phone on this line still works






Below picture is taken after step 2a and 2b. The empty socket port in red circle is for step 2d for your existing phone.



4. Get the wireless smart door/window sensors out of the box. Each smart sensor has two pieces. One is the main sensor side. The other is a slim magnet part. The main sensor is battery powered. Before we ship to you, we already put the battery in place. So all you need to do is to separate the sensor from its magnet counterpart and make sure the light blinks for a second.

5. Get the wireless motion sensors out of the box. Get the two wireless control fobs out of the box.
6. Now you can power up the main panel. Power it up by turning the switch in the back panel on. The system will boot up. After a minute or two, the LCD display window will show like below.
7. The system comes with two kinds of passwords. One is user level password used to arm/disarm the alarm system. The default password for user is "1111". Another password is for administrator to change settings. The default administrator password is "1234". You can change these passwords after you went through all steps in this guide.
8. If you have setup either GSM or PSTN phone line, for now you only need to add one setting as below.

- a. Press "Setting" () button and enter "1234", and then the big circle "OK" () button. It will show a setting menu.
- b. Scroll down using button "Down" () to get to "**Phone No. Setting**". The "Down" button shares same button as "disarm". Press "OK" button to enter phone number settings. This will set the phone numbers you want to get called when alarm is triggered. Enter the phone numbers here.

Alarm Receiving Phone Number

This alarm system can totally preset up to 5 personal emergency phone numbers for alarm receiving.

Time Setting	
Phone No. Setting	
SMS Setting	
Record	>

Phone Groups	1
Alarm Call	>
28901540	


Touch "◀▶" to select the Alarm Call or Alarm SMS, then touch "▼", you can input the number.

1st and 2nd group for setting Alarm SMS, 3rd group for setting Alarm SMS or Alarm Call, 4th&5th groups for setting Alarm Call.

Touch "◀X" you can delete the existing phone number.

You need touch "OK" to save, and navigate into next phone number setting menu.

Notice: Maximum digitals for phone number input is 15.

9. Once you are done setting up phone numbers. You can press "Return" () to get out of setting state.

10. Try one of the door sensors by separating its magnet part. You will hear a few quick beeps from the panel. The panel will also show "Zone 11 door sensor open" or "Zone 12 door sensor open". Zone 11, 12, 13, 14 are pre-configured for the included door sensors.
11. Put the magnet part back to stay with its sensor part.
12. Try the same steps for the other sensor.
13. Now test the motion sensors. These sensors come with AA batteries but you need to open the motion sensors and install batteries accordingly. Please refer to a separate instruction page for detailed motion sensor adjustments. After you installed batteries and after a few seconds, wave your hands over the middle of sensor to see the light turned on for a second. Your hands triggered a motion event. The panel will also show "Zone 21/22 PIR test status". It means the panel received the motion event. Zone 21 and 22 are pre-configured for the included motion sensors.
14. Put the motion sensors facing to a direction where no moving things going. So that we can continue test alarm features without too much disturbance.
15. Now, use remote control fob and press "Arm" button. The system will start to beep for 30 seconds and then will display "Away Arm" on the panel.
16. Once the system is in armed state, separating any one of the door sensors will trigger alarm. Press "Disarm" button on remote control fob to get rid of the alarm.
17. Once the system is in armed state, wave your hands in front of motion sensor to trigger motion alarm. Again press "Disarm" button on remote control fob to cancel the alarm.
18. Repeat above "Arm/Disarm" steps with touch keys on the main panel. On the main panel, when you press "Disarm" button, you will need to enter user level password to disarm.
19. Now, carry a remote fob with you and bring door sensors and motion sensors to the desired door/area where you would plan to install these sensors. Test "Arm/Disarm" and trigger of alarms there. Do not install them there yet.
20. Each time when an alarm gets triggered, after several seconds, the panel will automatically call your phone numbers you put in the panel. You can answer the phone to hear what is going on. If you don't answer the phone, the next phone number in the panel will be called.
21. After all these testing done, it is time to put the sensors up to the locations you want and start to enjoy the benefit of the alarm system. Please follow the manual booklet on how to correctly install those sensors. Attached also has a dedicated page on how to mount and set PIR motion sensor.
22. Mounting the door sensor is relatively easy. There are some instructions in the manual. In essence, the back plate of its main part has two hooks to secure the main sensor part. Please ensure the mounting direction of back plate so that the two hooks face up. The door sensor should be mounted at least 5 feet above ground so that kids won't accidentally hit it. The main part should be on door's frame and the small magnet part should be on the door. Their gap in between should be less than half inch. The back plate of main sensor part can be glued to doorframe using the provided double-sided glue

tape. Make sure the surface is clean before applying glue. The provided glue tape is very strong, however If the surface is not smooth, or if you want to ensure the stability, you can use the included screws to secure the back plate, in addition to the glue tape. You should be able to find those (8) screws in a plastic bag inside alarm panel box.

23. For other updates such as changing passwords, setting PSTN tone timer, setting speed dial numbers, system time settings, temperature threshold settings, SMS number setting, alarm delay, entry delay, detailed Zone attribute settings and auto arm/disarm settings, please follow the manual.

Thank you for your business. When you have time, please go back to the site where you have purchased this product and leave your review/feedback. Your review will be very helpful to future customers. It will also be very helpful for us to improve our procedure etc. Thanks again.

We have very low price on extra sensors such as extra key fob, smoke, water, etc.

They are available at www.intguard.com

Please also take a look at our video instruction page on adding new sensors etc.:

<http://www.intguard.com/pages/video-instructions>

IntGuard Inc.

www.intguard.com

Any queries please email to support@intguard.com

Customer is our number one priority



Preprogrammed sensors:

The 4 door sensors are usually pre-programmed into Zone 11 – Zone 15

The 2 PIR motion sensors are usually pre-programmed into Zone 21, 22

When those sensors are triggered, you can see which sensor is in which zone on the panel screen.

TERMS & CONDITIONS

BY USING IntGuard, INC.'S PRODUCTS, DEVICES AND APPS, YOU AGREE TO THE FOLLOWING TERMS AND CONDITIONS, INCLUDING ANY AMENDMENTS OR UPDATES. YOU SPECIFICALLY ACKNOWLEDGE YOU HAVE READ THE ENTIRETY OF THIS AGREEMENT AND UNDERSTAND ALL THE TERMS AND CONDITIONS OF THIS AGREEMENT, INCLUDING, BUT NOT LIMITED TO, PARAGRAPH 2, LIMITATION OF LIABILITY, PARAGRAPH 3, LIMITED WARRANTY, AND PARAGRAPH 4, INDEMNIFICATION AND SUBROGATION WAIVER. THIS VERSION OF TERMS & CONDITIONS IS EFFECTIVE ON April 21, 2014.

IMPORTANT TERMS AND CONDITIONS

1. **Definitions.** This paragraph shall define certain terms as used throughout this Agreement. "Agreement" shall refer to this Agreement. "Product" shall mean the Home Security System, Motion Sensors, Contact Sensors and applications ("apps") You purchased, acquired, or use. "Premises" shall refer to the location where You chose to use the Product. "Company" and/or "IntGuard" shall refer to and include IntGuard, Inc., its owners, directors, officers, shareholders, partners, subcontractors, independent contractors, employees, distributors, retailers, agents, and assigns. "You" and "Your" shall refer to the individual(s) who purchase, acquire and/or use the Product, download the app, and/or execute this Agreement.

2. **LIMITATION OF LIABILITY, WAIVER, AND LIQUIDATED DAMAGES.** IT IS UNDERSTOOD AND AGREED: INTGUARD AND ITS DIRECTORS, OFFICERS, SHAREHOLDERS, PARTNERS, SUBCONTRACTORS, DISTRIBUTORS, RETAILERS, AGENTS AND INDEPENDENT CONTRACTORS ARE NOT INSURERS NOR IS THIS AGREEMENT INTENDED TO BE AN INSURANCE POLICY OR A SUBSTITUTE FOR AN INSURANCE POLICY. YOU ACKNOWLEDGE AND AGREE THAT THE PRODUCT DOES NOT OFFER GUARANTEED PROTECTION AGAINST BURGLARY, ROBBERY, THEFT, PROPERTY DAMAGE, BODILY INJURY OR ANY OTHER TYPE OF EMERGENCY OR DAMAGE. YOU ARE SOLELY RESPONSIBLE FOR DETERMINING YOUR INSURANCE NEEDS, AND PURCHASING ANY NECESSARY INSURANCE. YOU AGREE TO LOOK SOLELY AND EXCLUSIVELY TO YOUR INSURER TO RECOVER ALL LOSS, DAMAGE, OR EXPENSE DUE TO LOSS AND/OR DAMAGE TO YOUR PERSONAL PROPERTY OR REAL PROPERTY ALLEGEDLY CAUSED BY THE PRODUCT. YOU ALSO AGREE TO LOOK SOLELY AND EXCLUSIVELY TO YOUR INSURER IN RESPONSE TO ANY CLAIM FOR BODILY INJURY AND/OR PERSONAL INJURY ALLEGEDLY CAUSED BY THE PRODUCT, INCLUDING CLAIMS MADE BY OR AGAINST YOU. YOU HEREBY RELEASE INTGUARD FROM ANY AND ALL LOSS, DAMAGE, AND/OR EXPENSE WHICH MAY OCCUR AS A RESULT OF YOUR USE, OR ATTEMPTED USE, OF THE PRODUCT, INCLUDING, BUT NOT LIMITED TO, THE FAILURE OF THE PRODUCT TO PERFORM, YOUR ALLEGED FAILURE TO COMPLY WITH ANY RELEVANT RULE, STATUTE, CODE, LAW OR ORDINANCE, AND ANY ACT OR OMISSION OF INTGUARD.

YOU ACKNOWLEDGE THAT IT IS IMPRACTICAL AND EXTREMELY DIFFICULT TO FIX THE ACTUAL DAMAGES, IF ANY, WHICH MAY PROXIMATELY RESULT FROM A

FAILURE OF THE PRODUCT, BECAUSE, AMONG OTHER THINGS: (A) THE AMOUNT OR VALUE OF PROPERTY ON THE PREMISES WHICH MAY BE LOST, STOLEN, DESTROYED, DAMAGED OR OTHERWISE AFFECTED BY A FAILURE OF THE PRODUCT IS UNCERTAIN; (B) THE AMOUNT OF POSSIBLE DAMAGES FOR BODILY INJURY OR DEATH IS UNCERTAIN; (C) WHAT PORTION, IF ANY, OF ANY LOSS AND/OR DAMAGE WAS PROXIMATELY CAUSED BY THE FAILURE OF THE PRODUCT IS UNCERTAIN; AND, (D) THE NATURE OF THE INCIDENTS THE PRODUCT IS MEANT TO ALERT YOU TO ARE UNPREDICTABLE.

YOU UNDERSTAND AND AGREE THAT YOUR RECOVERY OF DAMAGES AGAINST INTGUARD FOR ANY FAILURE OF THE PRODUCT, OR ANY ACT OR OMISSION OF INTGUARD, IS LIMITED TO THE AMOUNT YOU PAID FOR THE PRODUCT. IN NO EVENT WILL INTGUARD BE LIABLE TO YOU FOR ANY LOST PROFITS, LOST SAVINGS OR INCIDENTAL, INDIRECT, SPECIAL OR CONSEQUENTIAL DAMAGES, ARISING OUT OF YOUR USE OR INABILITY TO USE THE PRODUCT OR THE BREACH OF THIS AGREEMENT, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. THE LIMITATION OF LIABILITY TO THE PRICE YOU PAID FOR THE PRODUCT ESTABLISHES INTGUARD'S EXCLUSIVE LIABILITY TO YOU, AND APPLIES WHERE INTGUARD IS ALLEGED TO BE, OR IS FOUND LIABLE FOR, ANY PERSONAL INJURY, DEATH, PROPERTY LOSS, OR DAMAGE, INCLUDING, WITHOUT LIMITATION, ANY GENERAL, DIRECT, INDIRECT, SPECIAL, INCIDENTAL, EXEMPLARY, STATUTORY OR CONSEQUENTIAL DAMAGE, RESULTING FROM ANY ALLEGED FAILURE OF THE PRODUCT. THIS LIMITATION OF LIABILITY SHALL APPLY IRRESPECTIVE OF CAUSE AND REGARDLESS OF WHETHER SUCH LAWSUIT OR OTHER CLAIM IS BASED UPON ACTIVE OR PASSIVE NEGLIGENCE, BREACH OF EXPRESS OR IMPLIED CONTRACT OR WARRANTY, CONTRIBUTION, INDEMNIFICATION, STRICT OR PRODUCT LIABILITY, FAILURE TO COMPLY WITH ANY APPLICABLE LAW, OR ANY OTHER FAULT OR FAILURE OF INTGUARD, OR THE PRODUCT. YOU ACKNOWLEDGE AND AGREE THAT YOU HAD THE OPPORTUNITY TO MODIFY THIS LIMITATION OF LIABILITY BY CONTACTING INTGUARD AND NEGOTIATING FOR INTGUARD'S ASSUMPTION OF GREATER LIABILITY.

3. LIMITED WARRANTY. INTGUARD WARRANTS THE PRODUCT AGAINST DEFECTS IN MATERIALS AND WORKMANSHIP WHEN USED AS INSTRUCTED BY INTGUARD'S USER MANUAL FOR A PERIOD OF ONE (1) YEAR FROM YOUR DATE OF PURCHASE. THIS WARRANTY IS NULL AND VOID IF PHYSICAL DAMAGE OCCURS TO THE PRODUCT IN ANY WAY, INCLUDING BUT NOT LIMITED TO: REMOVAL OR REPLACEMENT OF ELECTRONIC COMPONENTS, INCORRECT BATTERY USAGE, REMOVAL OF DEVICE SHELL OR CASING, ACCESSING THE INTERIOR OF THE PRODUCT WITH THE EXCEPTION OF BATTERY REPLACEMENT IN COMPLIANCE WITH THE OWNER'S MANUAL, AND/OR ANY ATTEMPT TO CIRCUMVENT OR ALTER THE PRODUCT'S PRESCRIBED OPERATION.

TO THE EXTENT PERMITTED BY LOCAL LAW, THIS WARRANTY AND THE REMEDIES SET FORTH ARE EXCLUSIVE AND IN LIEU OF ALL OTHER WARRANTIES, REMEDIES AND CONDITIONS, WHETHER ORAL, WRITTEN, STATUTORY, EXPRESS OR IMPLIED. INTGUARD DISCLAIMS ALL STATUTORY AND IMPLIED WARRANTIES, INCLUDING WITHOUT LIMITATION, WARRANTIES OF

MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE AND WARRANTIES AGAINST HIDDEN OR LATENT DEFECTS, TO THE EXTENT PERMITTED BY LAW. TO THE EXTENT SUCH WARRANTIES CANNOT BE DISCLAIMED, INTGUARD LIMITS THE DURATION AND REMEDIES OF SUCH WARRANTIES TO THE DURATION OF THIS EXPRESS WARRANTY AND, AT INTGUARD'S OPTION, THE REPAIR OR REPLACEMENT SERVICES DESCRIBED BELOW.

INTGUARD'S LIMITED WARRANTY COVERS ONLY THOSE DEFECTS ARISING FROM NORMAL USE OF THE PRODUCT AND DOES NOT COVER ANY OTHER PROBLEMS, INCLUDING THOSE ARISING FROM: (1) IMPROPER MAINTENANCE; (2) SOFTWARE, MEDIA, PARTS OR SUPPLIES NOT PROVIDED OR SUPPORTED BY INTGUARD; (3) OPERATION OUTSIDE THE PRODUCT'S SPECIFICATIONS; (4) ABUSE OF THE PRODUCT; (5) NORMAL WEAR AND TEAR; OR, (6) UNAUTHORIZED MODIFICATION, ALTERATION, OR MISUSE.

4. INDEMNIFICATION AND SUBROGATION WAIVER. IN THE EVENT THAT ANY LAWSUIT OR OTHER CLAIM IS FILED OR MADE BY ANY THIRD PARTY AGAINST INTGUARD WHICH IS BASED ON OR ARISES OUT OF THE PRODUCT, INCLUDING, BUT NOT LIMITED TO CLAIMS AND LAWSUITS ALLEGING THE PRODUCT FAILED TO PERFORM IN ANY RESPECT WHATSOEVER, YOU AGREE TO BE SOLELY RESPONSIBLE FOR AND SHALL INDEMNIFY, SAVE, DEFEND, AND HOLD INTGUARD HARMLESS FROM AND AGAINST ALL SUCH CLAIMS INCLUDING PAYMENT OF ALL INTGUARD'S DAMAGES, EXPENSES, COSTS, AND ATTORNEYS' FEES INCURRED IN RESPONSE TO THE CLAIM OR LAWSUIT. THESE OBLIGATIONS APPLY IRRESPECTIVE OF CAUSE AND REGARDLESS OF WHETHER SUCH LAWSUIT OR OTHER CLAIM IS BASED UPON ACTIVE OR PASSIVE NEGLIGENCE, BREACH OF EXPRESS OR IMPLIED CONTRACT OR WARRANTY, CONTRIBUTION, INDEMNIFICATION, STRICT OR PRODUCT LIABILITY, FAILURE TO COMPLY WITH ANY APPLICABLE LAW, OR ANY OTHER FAULT OR FAILURE OF INTGUARD, OTHERS OR THE PRODUCT. YOU AGREE TO INDEMNIFY, SAVE, DEFEND, AND HOLD INTGUARD HARMLESS FROM ALL CLAIMS AND/OR LAWSUITS FOR SUBROGATION WHICH MAY BE BROUGHT AGAINST INTGUARD BY ANY INSURER OR INSURANCE COMPANY OR ITS AGENTS OR ASSIGNS INCLUDING THE PAYMENT OF ALL INTGUARD DAMAGES, EXPENSES, COSTS, AND ATTORNEYS' FEES. YOU HEREBY WAIVE ALL CLAIMS FOR RECOVERY AGAINST INTGUARD FOR ANY LOSS OR DAMAGE TO ANY PROPERTY OR LOSS INSURED UNDER VALID OR COLLECTIBLE INSURANCE POLICIES. THIS WAIVER OF SUBROGATION RIGHT SHALL EXTEND TO ALL FORMS OF SUBROGATION, INCLUDING, BUT NOT LIMITED TO, EQUITABLE AND CONVENTIONAL SUBROGATION, AND SHALL BE BINDING ON ANY AND ALL ASSIGNEES OR SUBROGEEES OF YOUR RIGHTS. IN NO EVENT MAY YOU ENTER INTO ANY SETTLEMENT OR LIKE AGREEMENT WITH A THIRD PARTY THAT AFFECTS INTGUARD'S RIGHTS OR BINDS INTGUARD IN ANY WAY, WITHOUT INTGUARD'S PRIOR WRITTEN CONSENT.

5. Installations and Use. You acknowledge and agree that the Product is a do-it-yourself product, and You are solely responsible for decisions related to the installation and use of the Product, including, but not limited to, the proper installation of the product, selection of the location for the Product, confirmation that the Product is properly

installed, testing the Product, ensuring that the Product is working, and compliance with all relevant rules, laws, statutes, codes, regulations, and/or ordinances. You acknowledge and agree that the Product does not provide traditional monitoring services and You are solely responsible for responding to any Phone Alerts, including contacting the appropriate authorities. You acknowledge and agree that You are not relying on IntGuard to install, repair, maintain, or monitor the Product, and agree and acknowledge that IntGuard cannot, and does not, ensure that the Product is installed or used correctly. It is solely Your obligation to advise IntGuard if there is an issue with the Product, and You, without limiting other releases in this Agreement, hereby release IntGuard from any damages, losses or expenses resulting from or as a consequence of issues related to the installation or use of the Product.

6. Additional Customer Duties, Responsibilities and Warranties. (A) Without in any way limiting the terms of Section 2, You acknowledge and agree that: (1) it is Your sole responsibility to comply with all rules, laws, statutes, codes, regulations, and/or ordinances, local, state, and federal, relevant to the use of the Product, including, but not limited to, those related to privacy rights, eavesdropping, surveillance, and obligations of alarm users; (2) the Product is for Your own use and not for the benefit of any other party; and, (3) it is your responsibility to generate as comprehensive password as possible to avoid being hijacked, and protect the password required to access Your account and the associated apps. (B) You acknowledge and agree that pursuant to Sections 2 and 4 of this agreement, You agree to waive any and all claims against IntGuard, and agree to fully defend and indemnify IntGuard, in response to any claim, demand and/or lawsuit arising out of (1) loss caused by unauthorized access to Your account, including, but not limited to the misplacement of Your password, loss of Your Password, or hijacking of Your password by unauthorized persons; and, (2) Your failure to comply with any rules, laws, statutes, codes, regulations, and/or ordinances, local, state, or federal, relevant to the use of the Product.

7. Limitations of Product. You acknowledge and agree that all alarm systems, including the Product, are subject to compromise or failure for reasons outside the control of the manufacturer, retailers and distributors, including, but not limited to: (a) Your misuse of the Product; (b) the ability of an intruder to gain access through an unprotected opening; (c) an intruder's technical sophistication enabling the intruder to bypass a sensor or the entire system; (d) signals sent by the Product may be blocked or reflected before being received; (e) a motion sensor's ability to detect an intrusion is limited to the designed ranges and unobstructed areas, and can be interfered with by other IR (infrared) signals; (f) the Products ability to function, including but not limited to automated phone alert, short message service ("SMS") alert, may be compromised by limited services by wireless phone carriers and other related service providers, internet connection dropout, limited speed of high-speed internet by ISP, limited service such as push notification provided by smartphone maker(s) and, (g) the Product, like any electrical system, is subject to component failures.

8. Binding Agreement; General Legal Matters. This Agreement becomes binding when You purchase the Product. The headings used herein are for the convenience of the parties only and shall not be considered in construing the provisions of this Agreement. Should any term, provision, or condition of this Agreement, or the application thereof shall be held to be invalid, unenforceable or void, the remainder of this Agreement and such term, provision, or condition as applied shall remain in full force and effect.

IntGuard™ G6 GSM Alarm System GSM Setup Guide

The GSM communication requires that you have good GSM signal reception at your installed location. The best way is to test your GSM signal with a traditional (GSM band only) cell phone to make sure you at least have two bar signal strength.

Once you decided to use GSM, please get a standard SIM card from your service provider and try the SIM card with your cell phone to make sure the SIM card can send and receive calls and SMS.

Now follow below steps to install the SIM card:

1. Turn off the G6 alarm host panel by unplugging its power cable **AND** also turn the switch to off on the back of the panel, right beside the power input.
2. On the back of the panel, you can see there is a SIM card slot as shown in below picture.
3. Using your thumb to slide the slot cover **towards** power input. The slot will open. You can lift the slot up as shown in below picture. Please do not use too much force on this. A little gentle force is enough.
4. Insert SIM card carefully. Do not force it in. A standard SIM card has a cut corner. The base of the slot also has a matching corner.
5. After the SIM card in place, gently press the slot back down and slide it to the opposite side of power input
6. Now turn on your power switch and re-insert the power cable. The alarm panel will boot up itself. In 10 seconds or so, it will report GSM signal and it will no longer display "no SIM Card".
7. With GSM communication, you can use the panel as a dial pad to dial any number you want and test the two-way communication is a success. So, dial it now to verify.
8. Follow the steps in manual to setup a SMS receiving number so that you also get all alerts/alarms via SMS and test alarm as needed.
9. For Android based smart phone, go to Google Play to search and install "Home alarm system". It is free. Contact support@intguard.com if any issue.

